
Meridian 1

Fiber Remote Multi-IPE Interface

Description, installation, and maintenance

Document Number: 553-3001-022

Document Release: Standard 2.00

Date: August 1996

© 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

April 1996

Standard, release 1.00.

August 1996

Standard, release 2.00. Incorporated changes to text, cabling, and included connection diagrams.

Contents

About this document	1
Reference	2
Product description	3
System overview	3
System description	4
Fiber Remote Multi-IPE Interface physical architecture	5
Fiber Remote Multi-IPE functional architecture	16
Engineering guidelines	25
Remote IPE capacity	25
Engineering the fiber-optic link	26
System selection	31
Remote IPE site planning	32
Installation and configuration	35
Quick reference to system installation and configuration	35
Installation overview	37
Preinstallation preparation	39
Preparing the site	39
Unpacking and inspection	40
Taking inventory	40
Installing the fiber-optic link	41
Selecting the Superloop Network card slot	43
Meridian 1 and fiber-optic equipment installation	44
Installing and verifying Meridian 1 operation	44
Installing the Superloop Network card	45

Installing cables between the Superloop Network card and the network I/O panel	46
Setting S1 and S2 switches at the local site	47
Installing redundant fiber-optic link option	53
Mounting the Fiber Remote Multi-IPE Interface units	56
Installing local superloop cables	61
Connecting local system monitor cables	61
Connecting the MMI terminal to a single Fiber Remote Multi-IPE Interface unit	64
Connecting the SDI port to a single Fiber Remote Multi-IPE Interface unit	65
Connecting the SDI card and the MMI terminal to multiple Fiber Remote Multi-IPE Interface units	66
Connecting the fiber-optic link	68
Connecting the external alarm cable at the local site	70
Connecting the power source	71
Remote IPE installation	76
Installing the internal cables to the Remote IPE module	76
Setting S1 and S2 switches at the remote site	77
Installing the Fiber Remote Multi-IPE Interface unit	81
Installing superloop cables	82
Connecting the system monitor cable	83
Connecting the MMI terminal	84
Connecting the fiber-optic link to the Remote IPE Module	86
Connecting the external alarm cable at the remote site	87
Connecting the power source at the remote site	88
Configuring the equipment	89
Factory default parameter settings	89
Configuring the cards	90
Configuring the Fiber Remote Multi-IPE Interface unit	94
Selecting the MMI terminal modes	94
Configuring the MMI modem	97
Configuring the Fiber Remote Multi-IPE Interface	100
Remote IPE acceptance testing	107
Acceptance testing overview	107

Checking the system	108
Setting up test conditions	109
Performing acceptance testing	109
Voice calls	110
Checking the MMI terminal operation	112
Checking link protection switching	112
Fault recovery test	114
Removing the test setup	115
Generating traffic reports	115
Remote IPE maintenance	117
Maintenance overview	117
Diagnostic tools	118
Hardware diagnostic tools	118
Software diagnostic tools	122
Isolating and correcting faults	130
Types of faults	130
Fault isolation steps	131
Remote IPE fault isolation and correction	132
Superloop Network card fault isolation and correction	134
Peripheral Controller card fault isolation and correction	138
Fault isolation and correction using MMI maintenance commands	140
Replacing Remote IPE equipment	150
Unpacking replacement equipment	150
Removing and replacing a card	150
Reinstalling covers	155
Packing and shipping defective cards	155
Appendix: Peripheral Controller HEX codes and cable connection diagrams	157
Peripheral Controller hexadecimal codes	158
Fiber Remote Multi-IPE Interface units connection diagrams	159